


Chapter 3 Drive And Motor Dimension

3.1 Drive Dimension

The user can install the servo drive with the bottom plate and the installed direction is perpendicular to the installation facing. Recommended to cool the servo drive with fan or natural cooling.



Pic 3.1 P100S-40/P100S-75 Dimension



◆ P100S-40 doesn't have the heat sink with a fan.